Clearing paper jams 1



By carefully selecting print media and loading them properly, you should be able to avoid most paper jams. If jams do occur, follow the steps outlined in this section.

To resolve the paper jam messages, you must clear the jammed area and then press **Go** to clear the message and resume printing. The printer prints a new copy of the page that jammed if Jam Recovery is set to On or Auto; however, the Auto setting does not guarantee the page will print.

Identifying paper jam areas

See the diagram **on page 2** for the path the paper travels through the printer and options, and areas where jams may occur. The path varies depending on the paper source and output bin.







Click a message below for more information.







Printing 200 Pa <x> Pa Using color

Paper handling







200 Paper Jam

<x> Pages Jammed (Check Areas A-F, T1-5, MPF)

This message identifies the areas (A-F, MPF, or T1-T5) you need to check to remove the paper or to clear the message. The display will alternate between 200 Paper Jam <x> Pages Jammed and Check Areas A-F., T1-5, MPF:

Jam message	Jam message
Check Areas A,B	Check Area F
Check Area C	Check MPF
Check Area D	Check T1-T4
Check Area E	Check T5

Note: If there is a paper jam when you turn the printer on, the second line of the **200 Paper Jam** message will be blank. To resolve the message, you must clear all paper from the paper path.



Index





Check Areas

A,B

This message indicates a paper jam in the transfer belt, fuser, or output roller area. To clear areas A–B:

1 Complete the steps to open the top cover.

Note: If you need instructions on how to open the top cover, see Opening the top cover.









Warning: Never touch the photodeveloper drum on the underside of the toner cartridge.

Note: The paper may be covered with unfused toner, which can stain garments.

2 Remove any paper on the transfer belt.

If the paper source was the multipurpose feeder, check the area between the multipurpose feeder and the transfer belt.



Warning: Do not use any pointed objects to remove the paper. This could cause permanent damage to the transfer belt.



www.lexmark.com





3 Check the fuser area and top cover for additional jams.

If there is no jam in the fuser area or top cover, close the top cover and front door, and then press **Go**. If a jam is present, continue with **step 4**.

Note: If you need instructions on how to close the top cover, see Closing the top cover.

4 Lift the fuser pressure release lever.









5 Slowly pull the paper out of the fuser toward the inside of the printer.





www.lexmark.com





6 Rotate the fuser pressure release lever down.



Note: The top cover will not close until the lever is in the down position.

7 Check the top cover for additional jams.

If there is no jam in the top cover, close the top cover and front door. If a jam is present, continue with **step 8**.







Note: If you need instructions on how to close the top cover, see Closing the top cover.

8 Remove the jam from the top cover.





www.lexmark.com





9 Close the top cover and the front door.

Note: If you need instructions on how to close the top cover, see Closing the top cover.

10 Open the jam access door on the left side of the printer.





www.lexmark.com





11 Remove any paper inside the printer.



12 Close the jam access door.

13 Press Go.

To prevent additional paper jams, make sure both sides of the door are closed.







Check Area C

Jams that cause a Check Area C message require opening the duplex jam access door. If you are printing on small paper, the following steps may not clear the jam. See Removing small size paper from the duplex unit.

1 Open the duplex jam access door on the right side of the printer.





Index

Printing

Using color

Paper handling

Maintenance

Troubleshooting

Administration

www.lexmark.com





2 Remove the jam.



3 Press Go.

If the paper jam message continues, check and clear all paper from the paper path.







Check Area D

This message indicates a paper jam in the duplex unit area. To clear area D:

1 Open the duplex jam access door on the right side of the printer.





www.lexmark.com





2 Gently pull out the duplex unit.





www.lexmark.com





3 Turn the paper forwarding dial counterclockwise.

If the paper advances out of the duplex unit, remove the jam and go to **step 7**. If the paper does not advance, go to step **step 4**.





www.lexmark.com





4 Open the duplex unit covers.





www.lexmark.com





5 Remove the jam.





www.lexmark.com





6 Close the duplex unit covers.





www.lexmark.com





7 Push the duplex unit until it stops.





www.lexmark.com



Clearing paper jams 21



8 Close the access door.



9 Press Go.

If the paper jam message continues, check and clear all paper from the paper path.



www.lexmark.com





Removing small size paper from the duplex unit

When printing on both sides of A5 or other small size paper, you may need to partially remove the duplex unit to clear the jam.

1 Turn off the printer.





www.lexmark.com





2 Open the duplex unit door.





www.lexmark.com









www.lexmark.com







www.lexmark.com





5 Remove jam from the duplex unit inlet.





www.lexmark.com





6 Slide the duplex unit in.





www.lexmark.com





- 7 Align the thumbscrews on the duplex unit with the holes in the printer.
- 8 Tighten the thumbscrews to secure the duplex unit.
- 9 Close the duplex unit door.





www.lexmark.com





Check Area E

This message indicates a jam in the top, middle, or bottom optional drawer paper path area.

Note: If you have a high capacity feeder, pull the feeder away from the printer.

1 Open the jam access door on the top optional drawer.





www.lexmark.com





2 Remove the jam.



3 Close the jam access door.



www.lexmark.com





4 Open the jam access door on the middle optional drawer.





www.lexmark.com





5 Remove the jam.



6 Close the jam access door.



www.lexmark.com





7 Open the jam access door on the bottom optional drawer.





www.lexmark.com





8 Remove the jam.



- 9 Close the jam access door.
- 10 Press Go.

If the paper jam message continues, check and clear all paper from the paper path.







Check Area F

1 Pull the high capacity feeder away from the printer.





www.lexmark.com





2 Open the jam access door on the top optional drawer.





www.lexmark.com



Clearing paper jams 37



3 Remove any jams.



4 Close the jam access door.



www.lexmark.com





5 Slide the high capacity feeder until the feeder locks to the docking frame.

When the feeder is in the correct position, you hear a *click*.



6 Press Go.

If the paper jam message continues, check and clear all paper from the paper path.







240 Paper Jam Check MP Feeder

1 Slowly pull the jam straight out of the multipurpose feeder.

If the paper will not come out, proceed with step 2.





www.lexmark.com





2 Open the top cover.

Note: If you need instructions on how to open the top cover, see Opening the top cover.

3 Remove the paper on the transfer belt.



www.lexmark.com



Clearing paper jams 41



Warning: Do not touch, drop, or place anything on the transfer belt. Touching the surface of the transfer belt or placing items on it may cause damage.





www.lexmark.com





4 Close the top cover.

Note: If you need instructions on how to close the top cover, see Closing the top cover.

5 Press Go.

24<x> Paper Jam Check Tray <x>

Jams in five areas result in a 24<x> Paper Jam message, where x represents the tray number where the jam has occurred. Paper jam messages 241–244 indicate a jam has occurred in one of the paper trays. A 249 Paper Jam Check Tray <x> message indicates a jam has occurred in the high capacity feeder. See Identifying paper jam areas for tray numbering.







241-244 Paper Jam

1 Pull out the tray indicated on the display.





www.lexmark.com





2 Remove any wrinkled or creased paper.





www.lexmark.com





3 Push down on the remaining paper in the tray until the bottom plate *clicks* into place.





www.lexmark.com





4 Close the tray.



5 Press Go.

If the paper jam message continues, check and clear all paper from the paper path.







249 Paper Jam Check Tray <x>

A 249 Paper Jam Check Tray <x> message indicates a jam has occurred in the high capacity feeder.

Note: If you have an optional printer cabinet, the high capacity feeder will be identified as tray 3.



www.lexmark.com





1 Open the top cover.





www.lexmark.com





2 Remove the jam.





www.lexmark.com





3 Close the top cover.







www.lexmark.com

