

Printing

Using color

Paper handling

Maintenance

Troubleshooting

Administration

Index

The Supplies Menu provides information about printer supplies that require attention. It is only available when a supply is low or needs replacement.

Select a menu item for more details:

- **<color>Toner**
- **Fuser**
- **Fuser Cleaner**
- **Oil Bottle**
- **Photo Dev Cart**
- **Tray <x> Status**
- **Waste Bottle**
- **Maintenance**
- **Replace Supplies**
- **Supplies Life**

[A](#) [B](#) [C](#) [D](#) [E](#) [F](#) [G](#) [H](#) [I](#) [J](#) [K](#) [L](#) [M](#) [N](#) [O](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [U](#) [V](#) [W](#) [X](#) [Y](#) [Z](#)
Menus



Printing

Using color

Paper handling

Maintenance

Troubleshooting

Administration

Index

<color>Toner

Purpose:

To view the status of the color print cartridges when in a maintenance state.

Values:

- Low** The <color> toner cartridge is low. If you do not have a replacement toner cartridge, you should order one at this time.
- Empty** You must replace the <color> toner cartridge to continue printing.

See also:

[Supplies](#)

[A](#) [B](#) [C](#) [D](#) [E](#) [F](#) [G](#) [H](#) [I](#) [J](#) [K](#) [L](#) [M](#) [N](#) [O](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [U](#) [V](#) [W](#) [X](#) [Y](#) [Z](#)
Menus



Printing

Using color

Paper handling

Maintenance

Troubleshooting

Administration

Index

Fuser

Purpose:

To view the status of the printer fuser when in a maintenance state.

Values:

Exhausted It's time to replace the fuser.

See also:

[Supplies](#)

[A](#) [B](#) [C](#) [D](#) [E](#) [F](#) [G](#) [H](#) [I](#) [J](#) [K](#) [L](#) [M](#) [N](#) [O](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [U](#) [V](#) [W](#) [X](#) [Y](#) [Z](#)
Menus



Printing

Using color

Paper handling

Maintenance

Troubleshooting

Administration

Index

Fuser Cleaner

Purpose:

To view the status of the printer fuser cleaning roll when in a maintenance state.

Values:

Missing	The cleaning roll is missing or improperly installed.
Life Warning	The cleaning roll is near its end of life.
Exhausted	It's time to replace the cleaning roll.

See also:

[Supplies](#)

[A](#) [B](#) [C](#) [D](#) [E](#) [F](#) [G](#) [H](#) [I](#) [J](#) [K](#) [L](#) [M](#) [N](#) [O](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [U](#) [V](#) [W](#) [X](#) [Y](#) [Z](#)
Menus



Printing

Using color

Paper handling

Maintenance

Troubleshooting

Administration

Index

Oil Bottle

Purpose:

To view the status of the printer oil bottle when in a maintenance state.

Values:

- Low** The oil bottle is low. If you do not have a replacement oil bottle, you should order one at this time.
- Empty** You must replace the oil bottle to continue printing.

See also:

[Supplies](#)

[A](#) [B](#) [C](#) [D](#) [E](#) [F](#) [G](#) [H](#) [I](#) [J](#) [K](#) [L](#) [M](#) [N](#) [O](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [U](#) [V](#) [W](#) [X](#) [Y](#) [Z](#)
Menus



Printing

Using color

Paper handling

Maintenance

Troubleshooting

Administration

Index

Photo Dev Cart

Purpose:

To view the status of the printer photo developer cartridge when in a maintenance state.

Values:

Missing

The photo developer cartridge is either missing or improperly installed.

Exhausted

It's time to replace the photo developer cartridge.

See also:

[Supplies](#)

[A](#) [B](#) [C](#) [D](#) [E](#) [F](#) [G](#) [H](#) [I](#) [J](#) [K](#) [L](#) [M](#) [N](#) [O](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [U](#) [V](#) [W](#) [X](#) [Y](#) [Z](#)
Menus



Printing

Using color

Paper handling

Maintenance

Troubleshooting

Administration

Index

Tray <x> Status

Purpose:

To view the status of all printer paper trays when in a maintenance state.

Values:

Missing Tray <x> is either missing or improperly installed.

Empty Tray <x> is empty.

See also:

[Loading paper, card stock, or labels](#)

[A](#) [B](#) [C](#) [D](#) [E](#) [F](#) [G](#) [H](#) [I](#) [J](#) [K](#) [L](#) [M](#) [N](#) [O](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [U](#) [V](#) [W](#) [X](#) [Y](#) [Z](#)
Menus



Printing

Using color

Paper handling

Maintenance

Troubleshooting

Administration

Index

Waste Bottle

Purpose:

To view the status of the printer waste toner bottle when in a maintenance state.

Values:

Near Full

The waste toner bottle is nearly full.

Full

It's time to empty or replace the waste toner bottle.

See also:

[Supplies](#)

[A](#) [B](#) [C](#) [D](#) [E](#) [F](#) [G](#) [H](#) [I](#) [J](#) [K](#) [L](#) [M](#) [N](#) [O](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [U](#) [V](#) [W](#) [X](#) [Y](#) [Z](#)
Menus



Printing

Using color

Paper handling

Maintenance

Troubleshooting

Administration

Index

Maintenance

Purpose:

To view the status of the maintenance kit when in a maintenance state.

Value:

120,000 Page Kit The Maintenance Kit needs to be replaced.

See also:

[Supplies](#)

[A](#) [B](#) [C](#) [D](#) [E](#) [F](#) [G](#) [H](#) [I](#) [J](#) [K](#) [L](#) [M](#) [N](#) [O](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [U](#) [V](#) [W](#) [X](#) [Y](#) [Z](#)
Menus



Printing

Using color

Paper handling

Maintenance

Troubleshooting

Administration

Index

Replace Supplies

Purpose:

To reset the counters for various supply items before they enter a maintenance state.

Values:

<color> Toner	=Not Replaced =Replaced
Photo Dev Cart	=Not Replaced =Replaced
Fuser	=Not Replaced =Replaced
Fuser Cleaner	=Not Replaced =Replaced

See also:

[Supplies](#)

[A](#) [B](#) [C](#) [D](#) [E](#) [F](#) [G](#) [H](#) [I](#) [J](#) [K](#) [L](#) [M](#) [N](#) [O](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [U](#) [V](#) [W](#) [X](#) [Y](#) [Z](#)
Menus



Printing

Using color

Paper handling

Maintenance

Troubleshooting

Administration

Index

Supplies Life

Purpose:

To view the current status of the printer supplies.

Supply items appear in the supplies list with the current percent life remaining or listed as OK. The percentage life remaining is replaced with the maintenance status once an item has reached a maintenance state for example, the waste bottle would change from **OK** to **Near Full**.

Values:

<color> Toner	=Empty =xx%	Photo Dev Cart	=Exhausted =xx% =Missing
Waste Bottle	=Near Full =Full or Missing =OK	Fuser	=Exhausted =xx%

[A](#) [B](#) [C](#) [D](#) [E](#) [F](#) [G](#) [H](#) [I](#) [J](#) [K](#) [L](#) [M](#) [N](#) [O](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [U](#) [V](#) [W](#) [X](#) [Y](#) [Z](#)
Menus



Printing

Using color

Paper handling

Maintenance

Troubleshooting

Administration

Index

Oil Bottle

=Low
=Empty
=OK

Fuser Cleaner

=Life Warning
=xx%
=Exhausted

See also:

Supplies

[A](#) [B](#) [C](#) [D](#) [E](#) [F](#) [G](#) [H](#) [I](#) [J](#) [K](#) [L](#) [M](#) [N](#) [O](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [U](#) [V](#) [W](#) [X](#) [Y](#) [Z](#)

Menus

