## **Product Power Consumption for Lexmark B3340dw / MS331dn**

Product Type	Monochrome Electrophotographic Printer
Default Method to automatically enter mode	Network Standby: 15 minute delay Standby: N/A Off: 3 Day Delay auto-off or switch activated

		Networ		Off	Standby Mode		
	All Network Connections	Wired Network	Fax	USB	Wireless	Mode	w/ Reactivation Function
Measurement Period	24 min	24 min	N/A	20 min	24 min	20 min	N/A
Average Power Consumption	0.83 W	0.95 W	N/A	0.76 W	1.00 W	0.06 W	N/A

Instructions for connecting to/disconnecting from a wireless network can be found in the product User Manual.

Report ID: 20190822-1091a-ErP

Public Report generation date: 31 Oct 2019