

## Product Power Consumption for Lexmark MS631dw

Product Type	Monochrome Electrophotographic Printer
Default Method to automatically enter mode	Network Standby: 15 minute delay Standby: 3 Day Delay Off: No auto-off; switch-activated only

	Network Standby					Off Mode	Standby Mode <i>w/ Reactivation Function</i>
	All Network Connections	Wired Network	Fax	USB	Wireless		
<b>Measurement Period (min)</b>	32	20	N/A	28	20	20	20
<b>Average Power Consumption</b>	0.80 W	0.79 W	N/A	0.73 W	0.72 W	0.09 W	0.09 W

Instructions for connecting to/disconnecting from a wireless network can be found in the product User Manual.

Report ID: 20221018-1214-ErP

Public Report generation date: 11/3/2022