Information guide

Help menu

The Help menu consists of a series of Help pages that are stored in the printer as PDF files. They contain information about using the printer and performing printing tasks.

English, French, German, and Spanish translations are stored in the printer. Other translations are available on the Lexmark Web site at **www.lexmark.com**.

Menu item	Description
Print All Guides	Prints all the guides
Color Quality	Provides information about adjusting and customizing color printing
Print Quality	Provides information about solving print quality issues
Printing Guide	Provides information about loading paper and other speciality media
Media Guide	Provides a list of the paper sizes supported in trays, drawers, and feeders
Print Defects Guide	Provides help in determining the printer part causing a repetitive defect
Menu Map	Provides a list of the printer control panel menus and settings
Information Guide	Provides help in locating additional information
Connection Guide	Provides information about connecting the printer locally (USB) or to a network
Moving Guide	Provides instructions for safely moving the printer
Supplies Guide	Provides part numbers for ordering supplies

Setup sheet

The setup sheet packaged with the printer provides information about setting up the printer and its options.

Software and Documentation CD

The *Software and Documentation* CD packaged with the printer includes a *User's Guide*. The *User's Guide* provides information about loading paper, printing, ordering supplies, troubleshooting, clearing jams, maintaining the printer, customizing the home screen, and using solutions.

For updates, check our Web site at http://support.lexmark.com.

Additional language support

The *User's Guide, Quick Reference,* and *Networking Guide* are available in other languages on the *Software and Documentation* CD.