

Tabuľka kompatibility voliteľného príslušenstva Lexmark

Popis	Číslo súčasti	Typ
APLIKAČNÉ RIEŠENIA		
Bezkontaktné overovacie zariadenie	57X0301	CS725de, CS720de, CS720dte, CS725dte, CS820dte, CS820dtfe, CS517de, CS727de, CS728de, CS827de, CS921de, CS923de, CS622de, CS730de, CS735de, CS943de, CS632dwe, CS963e, CS510de, CS510dte, C2132, CS820de, MS822de, MS632dwe, MS812de, MS610de, MS810de, MS610dte, M3150, MS911de, M5155, M5163, M5170, CX725de, CX725dhe, CX725dthe, CX820dtfe, CX825dte, CX825dtfe, CX860dte, CX860dtfe, XC8155de, XC8155dte, XC8160de, CX517de, CX727de, CX827de, CX920de, CX921de, CX922de, CX923dte, CX923dxe, CX924dte, CX924dxe, CX622ade, CX625ade, CX625adhe, CX625de, CX622de, CX735adse, CX730de, CX930dse, CX931dse, CX931dtse, Lexmark CX942adse, Lexmark CX943adtse, CX943adxse, Lexmark CX944adtse, CX944adxse, CX532adwe, CX635adwe, CX961se, CX962se, CX963se, CX833se, CX950se, CX951se, CX510de, CX510dhe, CX510dthe, XC2132, CX860de, CX825de, CX820de, MX517de, MX617de, MX717de, MX718de, MX622ade, MX622adhe, MX822ade, MX822adxse, MX826ade, MX826adxse, MX722adhe, MX721ade, MX721adhe, MX722ade, MX622de, MX822de, MX722dhe, MX826de, MX722de, MX931dse, MX432adwe, MX532adwe, MX632adwe, MX953se, MX611de, MX511de, MX611dhe, MX511dhe, MX510de, MX511dte, MX812dfe, MX812dpe, MX812dxfe, MX812dxpe, MX812dme, MX812dxme, MX811dfe, MX811dpe, MX811dme, MX811dxfe, MX811dxpe, MX811dxme, MX810dfe, MX810dpe, MX810dme, MX810dxfe, MX810dxpe, MX810dxme, MX711de, MX710de, MX710dhe, MX711dhe, XM3150, MX911de, MX910de, MX912de, MX910dxe, XM5163, XM5170, XM7155, XM7163, XM7170, XM7155x, XM7163x, XM7170x, XM1145, XM3150
Bezkontaktné overovacie zariadenie (Primárna voľba)	57X0235	CS730de, CS735de, CS943de, CS632dwe, CS963e, MS632dwe, CX735adse, CX730de, CX930dse, CX931dse, CX931dtse, Lexmark CX942adse, Lexmark CX943adtse, CX943adxse, Lexmark CX944adtse, CX944adxse, CX532adwe, CX635adwe, CX961se, CX962se, CX963se, CX833se, CX950se, CX951se, MX931dse, MX432adwe, MX532adwe, MX632adwe, MX953se
Elatec Reader Authentication Device	57X0210	CS725de, CS720de, CS720dte, CS725dte, CS820dte, CS820dtfe, CS517de, CS727de, CS728de, CS827de, CS921de, CS923de, CS622de, CS730de, CS735de, CS963e, CS510de, CS510dte, C2132, CS820de, MS822de, MS812de, MS610de, MS810de, MS610dte, M3150, MS911de, M5155, M5163, M5170, CX725de, CX725dhe, CX725dthe, CX820dtfe, CX825dte, CX825dtfe, CX860dte, CX860dtfe, XC8155de, XC8155dte, XC8160de, CX517de, CX727de, CX827de, CX921de, CX922de, CX923dte, CX923dxe, CX924dte, CX924dxe, CX622ade, CX625ade, CX625adhe, CX625de, CX622de, CX735adse, CX730de, CX961se, CX962se, CX963se, CX833se, CX950se, CX951se, CX510de, CX510dhe, CX510dthe, XC2132, CX860de, CX825de, CX820de, MX517de, MX617de, MX717de, MX718de, MX622ade, MX622adhe, MX822ade, MX822adxse, MX826ade, MX826adxse, MX722adhe, MX721ade, MX721adhe, MX722ade, MX622de, MX822de, MX722dhe, MX826de, MX722de, MX953se, MX611de, MX511de, MX611dhe, MX511dhe, MX510de, MX511dte, MX812dfe, MX812dpe, MX812dxfe, MX812dxpe, MX812dme, MX812dxme, MX811dfe, MX811dpe, MX811dme, MX811dxfe, MX811dxpe, MX811dxme, MX810dfe, MX810dpe, MX810dme, MX810dxfe, MX810dxpe, MX810dxme, MX711de, MX710de, MX710dhe, MX711dhe, XM3150, MX911de, MX910de, MX912de, MX910dxe, XM5163, XM5170, XM7155, XM7163, XM7170, XM7155x, XM7163x, XM7170x, XM1145, XM3150
Karta formulárov a karta čiarových kódov C950	22Z0182	C950de
Karta formulárov a čiarového kódu pre X950, X952, X954	22Z0185	X950de, X952de, X954de, X950dhe, XS950de, XS955de
Karta na IPDS pre X950, X952, X954	22Z0186	X950de, X952de, X954de, X950dhe, XS950de, XS955de
Karta na emuláciu PRESCRIBE pre C950	22Z0184	C950de
Karta na emuláciu PRESCRIBE pre X950, X952, X954	22Z0187	X950de, X952de, X954de, X950dhe, XS950de, XS955de
Karta na emuláciu jazyka PRESCRIBE	21K0129	CS820dte, CS820dtfe, CS827de, CS820de, CX820dtfe, CX825dte, CX825dtfe, CX860dte, CX860dtfe, XC8155de, XC8155dte, XC8160de, CX827de, CX860de, CX825de, CX820de
Karta na emuláciu jazyka PRESCRIBE	40C9202	CS725de, CS720de, CS720dte, CS725dte, CS727de, CS728de, CS921de, CS923de, CS421dn, CS521dn, CS622de, C2425dw, C2535dw,

Popis	Číslo súčasti	Typ
		CS431dw, MS521dn, MS621dn, B2650dn, MS622de, B2546dw, B2650dw, MS825dn, MS826de, MS725dvn, MS821n, MS821dn, MS822de, MS823n, MS823dn, B2865dw, CX725de, CX725dhe, CX725dthe, CX727de, CX920de, CX921de, CX922de, CX923dte, CX923dxe, CX924dte, CX924dxe, CX421adn, CX522ade, CX622ade, CX625ade, CX625adhe, MC2425adw, MC2535adwe, MC2640adwe, CX522de, CX625de, CX622de, MX421ade, MB2442adwe, MX521de, MX521ade, MX522adhe, MX622ade, MX622adhe, MB2546adwe, MB2650adwe, MX822ade, MX822adxe, MX826ade, MX826adxe, MX722adhe, MX721ade, MX721adhe, MX722ade, MB2770adhwe, MX522dhe, MX622de, MX822de, MX722dhe, MX826de, MX722de
Karta pre IPDS C950	22Z0183	C950de
Karta pre formuláre a čiarové kódy	21K0127	CS820dte, CS820dtfe, CS827de, CS820de, CX820dtfe, CX825dte, CX825dtfe, CX860dte, CX860dtfe, XC8155de, XC8155dte, XC8160de, CX827de, CX860de, CX825de, CX820de
Karta pre formuláre a čiarové kódy	40C9200	CS725de, CS720de, CS720dte, CS725dte, CS727de, CS728de, CS921de, CS923de, CS421dn, CS521dn, CS622de, C2425dw, C2535dw, CS431dw, MS521dn, MS621dn, B2650dn, MS622de, B2546dw, B2650dw, MS825dn, MS826de, MS725dvn, MS821n, MS821dn, MS822de, MS823n, MS823dn, B2865dw, CX725de, CX725dhe, CX725dthe, CX727de, CX920de, CX921de, CX922de, CX923dte, CX923dxe, CX924dte, CX924dxe, CX421adn, CX522ade, CX622ade, CX625ade, CX625adhe, MC2425adw, MC2535adwe, MC2640adwe, CX522de, CX625de, CX622de, MX421ade, MB2442adwe, MX521de, MX521ade, MX522adhe, MX622ade, MX622adhe, MB2546adwe, MB2650adwe, MX822ade, MX822adxe, MX826ade, MX826adxe, MX722adhe, MX721ade, MX721adhe, MX722ade, MB2770adhwe, MX522dhe, MX622de, MX822de, MX722dhe, MX826de, MX722de
Karta pre jazyk IPDS	21K0128	CS820dte, CS820dtfe, CS827de, CS820de, CX820dtfe, CX825dte, CX825dtfe, CX860dte, CX860dtfe, XC8155de, XC8155dte, XC8160de, CX827de, CX860de, CX825de, CX820de
Karta pre jazyk IPDS	40C9201	CS725de, CS720de, CS720dte, CS725dte, CS727de, CS728de, CS921de, CS923de, MS521dn, MS621dn, B2650dn, MS622de, B2546dw, B2650dw, MS825dn, MS826de, MS725dvn, MS821n, MS821dn, MS822de, MS823n, MS823dn, B2865dw, CX725de, CX725dhe, CX725dthe, CX727de, CX920de, CX921de, CX922de, CX923dte, CX923dxe, CX924dte, CX924dxe, MX421ade, MB2442adwe, MX521de, MX521ade, MX522adhe, MX622ade, MX622adhe, MB2546adwe, MB2650adwe, MX822ade, MX822adxe, MX826ade, MX826adxe, MX722adhe, MX721ade, MX721adhe, MX722ade, MB2770adhwe, MX522dhe, MX622de, MX822de, MX722dhe, MX826de, MX722de
Kontaktné overovacie zariadenie	57X0300	CS725de, CS720de, CS720dte, CS725dte, CS820dte, CS820dtfe, CS517de, CS727de, CS728de, CS827de, CS921de, CS923de, CS622de, CS730de, CS735de, CS943de, CS632dwe, CS963e, CS510de, CS510dte, C2132, CS820de, MS622de, MS826de, MS822de, MS632dwe, MS812de, MS610de, MS810de, MS610dte, M3150, MS911de, M5155, M5163, M5170, CX725de, CX725dhe, CX725dthe, CX820dtfe, CX825dte, CX825dtfe, CX860dte, CX860dtfe, XC8155de, XC8155dte, XC8160de, CX517de, CX727de, CX827de, CX920de, CX921de, CX922de, CX923dte, CX923dxe, CX924dte, CX924dxe, CX522ade, CX622ade, CX625ade, CX625adhe, CX522de, CX625de, CX622de, CX735adse, CX730de, CX930dse, CX931dse, CX931dtse, Lexmark CX942adse, Lexmark CX943adtse, CX943adxse, Lexmark CX944adtse, CX944adxse, CX532adwe, CX635adwe, CX961se, CX962se, CX963se, CX833se, CX950se, CX951se, CX510de, CX510dhe, CX510dthe, XC2132, CX860de, CX825de, CX820de, MX517de, MX617de, MX717de, MX718de, MX522adhe, MX622ade, MX622adhe, MX822ade, MX822adxe, MX826ade, MX826adxe, MX722adhe, MX721ade, MX721adhe, MX722ade, MX522dhe, MX622de, MX822de, MX722dhe, MX826de, MX722de, MX931dse, MX432adwe, MX532adwe, MX632adwe, MX953se, MX611de, MX511de, MX611dhe, MX511dhe, MX510de, MX511dte, MX812dfe, MX812dpe, MX812dxfe, MX812dxpe, MX812dme, MX812dxme, MX811dfe, MX811dpe, MX811dme, MX811dxfe, MX811dxpe, MX811dxme, MX810dfe, MX810dpe, MX810dme, MX810dxfe, MX810dxpe, MX810dxme, MX711de, MX710de, MX710dhe, MX711dhe, XM3150, MX911de, MX910de, MX912de, MX910dxe, XM5163, XM5170, XM7155, XM7163, XM7170, XM7155x, XM7163x, XM7170x, XM1145, XM3150
Licencia IPDS	82S1203	CS730de, CS735de, CS531dw, CS632dwe, CS963e, MS531dw, MS631dw, MS632dwe, CX735adse, CX730de, CX532adwe,

Popis	Číslo súčasti	Typ
		CX635adwe, CX961se, CX962se, CX963se, CX833se, CX950se, CX951se, MX532adwe, MX632adwe, MX953se
Licencia čiarového kódu	82S1204	CS730de, CS735de, CS531dw, CS632dwe, CS963e, MS531dw, MS631dw, MS632dwe, CX735adse, CX730de, CX532adwe, CX635adwe, CX961se, CX962se, CX963se, CX833se, CX950se, CX951se, MX532adwe, MX632adwe, MX953se
MS810de Karta pre formuláre a čiarové kódy	40G0830	MS810de, M5155, M5163
MS810de Karta pre jazyk IPDS	40G0831	MS810de, M5155, M5163
MS812de Karta na emuláciu jazyka PRESCRIBE	40G0847	MS812de, MS812de with 2-Year Onsite Guarantee, M5170
MS812de Karta pre formuláre a čiarové kódy	40G0840	MS812de, MS812de with 2-Year Onsite Guarantee, M5170
MS812de Karta pre jazyk IPDS	40G0841	MS812de, MS812de with 2-Year Onsite Guarantee, M5170
MS81xn, dn Karta na emuláciu jazyka PRESCRIBE	40G0817	MS817dn, MS818dn, MS812dn, MS811dn, MS810dn, MS812dn, MS810n, MS811n, MS810dn, MS811dn, MS711dn, MS710dn
MS81xn, dn Karta pre formuláre a čiarové kódy	40G0810	MS817dn, MS818dn, MS812dn, MS811dn, MS810dn, MS812dn, MS810n, MS811n, MS810dn, MS811dn, MS711dn, MS710dn
MS81xn, dn Karta pre jazyk IPDS	40G0811	MS817dn, MS818dn, MS812dn, MS811dn, MS810dn, MS812dn, MS810n, MS811n, MS810dn, MS811dn, MS711dn, MS710dn
MS911 Karta na emuláciu jazyka PRESCRIBE	26Z0025	MS911de
MS911 Karta pre formuláre a čiarové kódy	26Z0023	MS911de
MS911 Karta pre jazyk IPDS	26Z0024	MS911de
MX71x, MX81x Karta na emuláciu jazyka PRESCRIBE	24T7353	MX717de, MX718de, MX812dfe, MX812dpe, MX812dxfe, MX812dxpe, MX812dme, MX812dxme, MX811dfe, MX811dpe, MX811dme, MX811dxfe, MX811dxpe, MX811dxme, MX810dfe, MX810dpe, MX810dme, MX810dxfe, MX810dxpe, MX810dxme, MX711de, MX710de, MX710dhe, MX711dhe, XM5163, XM5170, XM7155, XM7163, XM7170, XM7155x, XM7163x, XM7170x
MX71x, MX81x Karta pre formuláre a čiarové kódy	24T7351	MX717de, MX718de, MX812dfe, MX812dpe, MX812dxfe, MX812dxpe, MX812dme, MX812dxme, MX811dfe, MX811dpe, MX811dme, MX811dxfe, MX811dxpe, MX811dxme, MX810dfe, MX810dpe, MX810dme, MX810dxfe, MX810dxpe, MX810dxme, MX711de, MX710de, MX710dhe, MX711dhe, XM5163, XM5170, XM7155, XM7163, XM7170, XM7155x, XM7163x, XM7170x
MX71x, MX81x Karta pre jazyk IPDS	24T7352	MX717de, MX718de, MX812dfe, MX812dpe, MX812dxfe, MX812dxpe, MX812dme, MX812dxme, MX811dfe, MX811dpe, MX811dme, MX811dxfe, MX811dxpe, MX811dxme, MX810dfe, MX810dpe, MX810dme, MX810dxfe, MX810dxpe, MX810dxme, MX711de, MX710de, MX710dhe, MX711dhe, XM5163, XM5170, XM7155, XM7163, XM7170, XM7155x, XM7163x, XM7170x
MX910, MX911, MX912 Karta na emuláciu jazyka PRESCRIBE	26Z0197	MX911de, MX910de, MX912de, MX910dxe
MX910, MX911, MX912 Karta pre jazyk IPDS	26Z0196	MX911de, MX910de, MX912de, MX910dxe
MX91x Karta pre formuláre a čiarové kódy	26Z0195	MX911de, MX910de, MX912de, MX910dxe
Stolná bezkontaktná čítačka	57X0225	CS730de, CS735de, CS943de, CS632dwe, CS963e, MS632dwe, CX735adse, CX730de, CX930dse, CX931dse, CX931dtse, Lexmark CX942adse, Lexmark CX943adtse, CX943adxse, Lexmark CX944adtse, CX944adxse, CX532adwe, CX635adwe, CX961se, CX962se, CX963se, CX833se, CX950se, CX951se, MX931dse, MX432adwe, MX532adwe, MX632adwe, MX953se