

Tabla de compatibilidad de opciones de Lexmark

Descripción	P/N	Modelo
MUEBLE		
Base con ruedas	21K2501	CS820dte, CS820dtfe, CS827de, CS820de, XC8155de, XC8160de, CX827de, CX860de, CX825de, CX820de
Base con ruedas	50G0855	MS825dn, MS826de, MS725dvn, MS821n, MS821dn, MS822de, MS823n, MS823dn, B2865dw, MX722adhe, MX721ade, MX721adhe, MX722ade, MB2770adwhe, MX722dhe, MX722de
C925, X925 Armario sobre base con ruedas	24Z0031	C925de, C925dte, X925de, XS925de, XS925de
CS92x, CX92xde Mueble con ruedas	32C0053	CS921de, CS923de, CX920de, CX921de, CX922de, CX923dte, CX923dxe, CX924dte, CX924dxe
CX92x, MX91x Mesa de trabajo	26Z0090	CX920de, CX921de, CX922de, CX923dte, CX923dxe, CX924dte, CX924dxe, MX911de, MX910de, MX912de, MX910dxe
CX93x/MX93x Mesa de trabajo	32D0808	Lexmark CX930dse, CX931dse, CX931dtse, Lexmark MX931dse
CX94x Mesa de trabajo	32D0809	Lexmark CX942adse, Lexmark CX943adtse, Lexmark CX943adxse, Lexmark CX944adtse, Lexmark CX944adxse
Estante del teclado	20L8807	CX961se, CX962se, CX963se, CX833se, CX950se, CX951se, MX953se
MS911, MX91xde Mueble con ruedas	26Z0094	MS911de, MX911de, MX910de, MX912de
Mueble	20L8806	CS963e, CX961se, CX962se, CX963se, CX833se, CX950se, CX951se, MX953se
Mueble ajustable	40C2300	CS725de, CS720de, CS720dte, CS725dte, CS727de, CS728de, CS521dn, CS622de, C3224dw, C3326dw, CS331dw, Lexmark CS431dw, C3426dw, CS730de, CS735de, Lexmark CS531dw, Lexmark CS632dwe, MS817dn, MS818dn, MS825dn, MS826de, MS725dvn, MS821n, MS821dn, MS822de, MS823n, MS823dn, MS812de, MS812dn, MS810de, MS811dn, MS810dn, MS812dtn, MS810n, MS811n, MS810dtn, MS811dtn, MS711dn, MS710dn, M5155, M5163, M5170, CX725de, CX725dhe, CX725dtse, CX727de, CX522ade, CX622ade, CX625ade, CX625adhe, MC3224adwe, CX331adwe, MC3224dwe, MC3326adwe, Lexmark CX431adw, MC3426adw, Lexmark MC3326i, Lexmark MC3426i, CX431dw, CX522de, CX625de, Lexmark MC3224i, CX622de, Lexmark CX735adse, CX730de, Lexmark CX532adwe, Lexmark CX635adwe, MX717de, MX718de, MX722adhe, MX721ade, MX721adhe, MX722ade, MB2770adwhe, MX722dhe, MX722de, MX711de, MX710de, MX710dhe, MX711dhe, XM5163, XM5170
Mueble ajustable	35S8502	CS317dn, CS417dn, CS517de, Lexmark CS431dw, CS510de, CS410dn, CS310dn, CS310n, CS410n, CS410dtn, CS510dte, C2132, MS517dn, MS617dn, MS321dn, B2338dw, MS421dn, MS421dw, B2442dw, MS521dn, MS621dn, MS622de, B2546dw, B2650dw, Lexmark MS331dn, Lexmark MS431dn, MS431dw, B3442dw, B3340dw, MS531dw, MS631dw, MS632dwe, MS610de, MS610dn, MS510dn, MS610dte, MS510dtn with 3 year Exchange Service, M1145, M3150, CX317dn, CX417de, CX517de, CX510de, CX410de, CX410e, CX510dhe, CX510dtse, CX410dte, CX310dn, CX310n, CX410de with 3 year Onsite Service, XC2130, XC2132, MX517de, MX617de, MX321adn, MX321adw, MB2338adw, MX421ade, MB2442adwe, MX521de, MX521ade, MX522adhe, MX622ade, MX622adhe, MB2546adwe, MB2650adwe, Lexmark MX331adn, Lexmark MX431adn, MB3442adw, Lexmark MB3442i, MX331dn, MX431dn, MX522dhe, MX622de, MX432adwe, MX532adwe, MX632adwe, MX611de, MX511de, MX611dhe, MX511dhe, MX510de, MX511dte, XM1145, XM3150, XM1145, XM1145 con 4 años garantía Parts Only (incluye Kit de Mantenimiento), XM3150, XM3150 con 4 años garantía Parts Only (incluye Kit de Mantenimiento)
Mueble giratorio	3073173	CS317dn, CS417dn, CS517de, CS421dn, CS521dn, CS622de, C2425dw, C2535dw, Lexmark CS431dw, Lexmark CS531dw, Lexmark CS632dwe, C748de, C746dn, C746dtn, C748dte, C746n, C748e, CS510de, CS410dn, CS310dn, CS310n, CS410n, CS410dtn, CS510dte, C2132, MS517dn, MS617dn, MS817dn, MS818dn, MS321dn, B2338dw, MS421dn, MS421dw, B2442dw, MS521dn, MS621dn, MS622de, B2546dw, B2650dw, MS825dn, MS826de, MS725dvn, MS821n, MS821dn, MS822de, MS823n, MS823dn, Lexmark MS331dn, Lexmark MS431dn, MS431dw, B3442dw, B3340dw, MS531dw, MS631dw, MS632dwe, MS812de, MS610de, MS812dn, MS810de, MS811dn, MS810dn, MS812dtn, MS810n, MS811n, MS810dtn, MS811dtn, MS610dn, MS510dn, MS610dte, MS711dn, MS710dn, MS510dtn with 3 year Exchange Service, MS812de with 2-Year Onsite Guarantee, M5155, M5163, M5170, M1145, M3150, CX317dn, CX417de, CX517de, CX421adn, CX522ade, CX622ade, CX625ade, CX625adhe,

Descripción	P/N	Modelo
		MC2425adw, MC2535adwe, MC2640adwe, CX522de, CX625de, CX622de, Lexmark CX532adwe, Lexmark CX635adwe, X748de, X748dte, X746de, CX510de, CX410de, CX410e, CX510dhe, CX510dthe, CX410dte, CX310dn, CX310n, CX410de with 3 year Onsite Service, XC2130, XC2132, MX517de, MX617de, MX717de, MX718de, MX321adn, MX321adw, MB2338adw, MX421ade, MB2442adwe, MX521de, MX521ade, MX522adhe, MX622ade, MX622adhe, MB2546adwe, MB2650adwe, MX722adhe, MX721ade, MX721adhe, MX722ade, MB2770adwhe, Lexmark MX331adn, Lexmark MX431adn, MB3442adw, Lexmark MB3442i, MX331dn, MX431dn, MX522dhe, MX622de, MX722dhe, MX722de, MX532adwe, MX632adwe, MX611de, MX511de, MX611dhe, MX511dhe, MX510de, MX511dte, MX711de, MX710de, MX710dhe, MX711dhe, XM1145, XM3150, XM5163, XM5170, XM1145, XM1145 con 4 años garantía Parts Only (incluye Kit de Mantenimiento), XM3150, XM3150 con 4 años garantía Parts Only (incluye Kit de Mantenimiento)