

Tabuľka kompatibility voliteľného príslušenstva Lexmark

Popis	Číslo súčasti	Typ
PAMÄŤ		
1024MB DDR2-DRAM	1025043	C734dn, C736dn, C736n, C736dtn, C734dtn, C734n, C734dw, C925de, C792de, C792dte, C792e, C792dhe, C950de, C748de, C746dn, C746dtn, C748dte, C746n, C748e, T654dn, T654dtn, T654n, W850n, W850dn, T656dne, X560n, X560dn, X736de, X738de, X734de, X738dte, X792de, X792dte, X792dtfe, X792dtme, X792dtpe, X792dtse, X548dte, X548de, X950de, X952de, X748de, X925de, X748dte, X746de, X950dhe, X925de, X950de, X651de, X652de, X654de, X656dte, X658dfe, X658dme, X658dtfe, X658dtme, X864de 4, X862de 4, X860de 4, X860de 3, X862de 3, X864de 3, X860de 4, X862de 4, X864de 4
1024MBx16 DDR3-DRAM	57X9011	MS517dn, MS617dn, MS610dn, MS510dn, M1145, M1145
1024MBx32 DDR3-DRAM	57X9016	CS317dn, CS417dn, CS517de, CS510de, CS410dn, CS310dn, CS310n, CS410n, CS410dtn, CS510dte, C2132, MS817dn, MS818dn, MS812de, MS610de, MS812dn, MS810de, MS811dn, MS810dn, MS812dtn, MS810n, MS811n, MS810dtn, MS811dtn, MS610dte, M3150, MS711dn, MS710dn, MS911de, MS812de with 2-Year Onsite Guarantee, M5155, M5163, M5170, M3150, CX317dn, CX417de, CX517de, CX510de, CX410de, CX410e, CX510dhe, CX510dthe, CX410dte, CX310dn, CX310n, XC2130, XC2132, MX417de, MX517de, MX617de, MX717de, MX718de, MX611de, MX511de, MX410de, MX611dhe, MX511dhe, MX510de, MX511dte, MX812dfe, MX812dpe, MX812dxfe, MX812dxpe, MX812dme, MX812dxme, MX811dfe, MX811dpe, MX811dme, MX811dxfe, MX811dxpe, MX811dxme, MX810dfe, MX810dpe, MX810dme, MX810dxfe, MX810dxpe, MX810dxme, MX711de, MX710de, MX710dhe, MX711dhe, XM3150, MX911de, MX910de, MX912de, MX910dxe, XM5163, XM5170, XM7155, XM7163, XM7170, XM7155x, XM7163x, XM7170x, XM1140, XM1145, XM3150, XM3150 with 3-years Parts Only (Maintenance Kit included)
2 GB x32 DDR3 RAM	57X9020	CS725de, CS720de, CS720dte, CS725dte, CS727de, CS728de, CS921de, CS923de, CX725de, CX725dhe, CX725dthe, CX727de, CX920de, CX921de, CX922de, CX923dte, CX923dxe, CX924dte, CX924dxe
2 GB x64 DDR3 RAM	57X9022	CS820dte, CS820dtfe, CS827de, CS820de, CX820dtfe, CX825dte, CX825dtfe, CX860dte, CX860dtfe, XC8155de, XC8155dte, XC8160de, CX827de, CX860de, CX825de, CX820de
2048MBx32 DDR3-DRAM	57X9012	CS317dn, CS417dn, CS517de, CS510de, CS410dn, CS310dn, CS310n, CS410n, CS410dtn, CS510dte, C2132, MS817dn, MS818dn, MS812de, MS610de, MS812dn, MS810de, MS811dn, MS810dn, MS812dtn, MS810n, MS811n, MS810dtn, MS811dtn, MS610dte, M3150, MS711dn, MS710dn, MS911de, MS812de with 2-Year Onsite Guarantee, M5155, M5163, M5170, M3150, CX317dn, CX417de, CX517de, CX510de, CX410de, CX410e, CX510dhe, CX510dthe, CX410dte, CX310dn, CX310n, XC2130, XC2132, MX417de, MX517de, MX617de, MX717de, MX718de, MX611de, MX511de, MX410de, MX611dhe, MX511dhe, MX510de, MX511dte, MX812dfe, MX812dpe, MX812dxfe, MX812dxpe, MX812dme, MX812dxme, MX811dfe, MX811dpe, MX811dme, MX811dxfe, MX811dxpe, MX811dxme, MX810dfe, MX810dpe, MX810dme, MX810dxfe, MX810dxpe, MX810dxme, MX711de, MX710de, MX710dhe, MX711dhe, XM3150, MX911de, MX910de, MX912de, MX910dxe, XM5163, XM5170, XM7155, XM7163, XM7170, XM7155x, XM7163x, XM7170x, XM1140, XM1145, XM3150, XM3150 with 3-years Parts Only (Maintenance Kit included)
256MB DDR2-DRAM	1025041	C734dn, C736dn, C736n, C736dtn, C734dtn, C734n, C734dw, C925de, C792de, C792dte, C792e, C792dhe, C950de, C748de, C746dn, C746dtn, C748dte, C746n, C748e, T654dn, T654dtn, T654n, W850n, W850dn, T656dne, X560n, X560dn, X736de, X738de, X734de, X738dte, X792de, X792dte, X792dtfe, X792dtme, X792dtpe, X792dtse, X548dte, X548de, X950de, X952de, X748de, X925de, X748dte, X746de, X950dhe, X925de, X950de, X651de, X652de, X654de, X656dte, X658dfe, X658dme, X658dtfe, X658dtme, X864de 4, X862de 4, X860de 4, X860de 3, X862de 3, X864de 3, X860de 4, X862de 4, X864de 4
4GBx32 DDR3-DRAM	57X0204	MS825dn, MS826de, MS725dvn, MS821n, MS821dn, MS822de, MS823n, MS823dn, B2865dw, CX522ade, CX622ade, CX625ade, CX625adhe,

Popis	Číslo súčasti	Typ
		MC2535adwe, MC2640adwe, CX522de, CX625de, CX622de, MX822ade, MX822adxe, MX826ade, MX826adxe, MX722adhe, MX721ade, MX721adhe, MX722ade, MB2770adhwe, MX822de, MX722dhe, MX826de, MX722de
500+ GB Hard Disk	27X0500	MS622de, MS825dn, MS826de, MS725dvn, MS821n, MS821dn, MS822de, MS823n, MS823dn, B2865dw, MS632dwe
500+ GB Hard Disk	27X0805	CS622de, CS632dwe, CX532adwe, CX635adwe
500GB Hard Disk Drive (SATA)	27X0420	CS963e, CX961se, CX962se, CX963se, CX833se, CX950se, CX951se, MX953se
512MB DDR2-DRAM	1025042	C734dn, C736dn, C736n, C736dtn, C734dtn, C734n, C734dw, C925de, C792de, C792dte, C792e, C792dhe, C950de, C748de, C746dn, C746dtn, C748dte, C746n, C748e, T654dn, T654dtn, T654n, W850n, W850dn, T656dne, X560n, X560dn, X736de, X738de, X734de, X738dte, X792de, X792dte, X792dtfe, X792dtme, X792dtpe, X792dtse, X548dte, X548de, X950de, X952de, X748de, X925de, X748dte, X746de, X950dhe, XS925de, XS950de, X651de, X652de, X654de, X656dte, X658dfe, X658dme, X658dtfe, X658dtme, X864de 4, X862de 4, X860de 4, X860de 3, X862de 3, X864de 3, XS860de 4, XS862de 4, XS864de 4
512MBx16 DDR3-DRAM	57X9014	MS517dn, MS617dn, MS610dn, MS510dn, M1145, M1145
Jednotka Intelligent Storage Drive (ISD)	57X9528	CS730de, CS735de, CS943de, CS531dw, CS632dwe, CS963e, MS531dw, MS631dw, MS632dwe, CX730de, CX930dse, CX931dse, CX931dtse, Lexmark CX942adse, Lexmark CX943adtse, CX943adxse, Lexmark CX944adtse, CX944adxse, CX532adwe, CX635adwe, MX931dse, MX432adwe, MX532adwe, MX632adwe
Karta s pamäťou flash s kapacitou 256 MB	57X9101	CS417dn, CS517de, CS921de, CS923de, CS510de, CS410dn, CS410n, CS410dtn, CS510dte, C2132, MS317dn, MS417dn, MS517dn, MS617dn, MS817dn, MS818dn, MS812de, MS610de, MS812dn, MS810de, MS811dn, MS810dn, MS812dtn, MS810n, MS811n, MS810dtn, MS811dtn, MS610dn, MS510dn, MS410dn, MS310dn, MS410d, MS310d, MS610dte, M1145, M3150, MS711dn, MS710dn, MS312dn, MS415dn, M1140+, MS911de, MS812de with 2-Year Onsite Guarantee, M5155, M5163, M5170, M1140+, M1145, M3150, CX317dn, CX417de, CX517de, CX920de, CX921de, CX922de, CX923dte, CX923dxe, CX924dte, CX924dxe, CX510de, CX410de, CX410e, CX510dhe, CX510dthe, CX410dte, CX310dn, CX310n, XC2130, XC2132, MX317dn, MX417de, MX517de, MX617de, MX717de, MX718de, MX611de, MX511de, MX410de, MX611dhe, MX511dhe, MX510de, MX310dn, MX511dte, MX812dfe, MX812dpe, MX812dxe, MX812dxpe, MX812dme, MX812dxme, MX811dfe, MX811dpe, MX811dme, MX811dxfe, MX811dxpe, MX811dxme, MX810dfe, MX810dpe, MX810dme, MX810dxe, MX810dxpe, MX810dxme, MX711de, MX710de, MX710dhe, MX711dhe, XM3150, MX911de, MX910de, MX912de, MX910dxe, XM5163, XM5170, XM7155, XM7163, XM7170, XM7155x, XM7163x, XM7170x, XM1140, XM1145, XM3150, XM3150 with 3-years Parts Only (Maintenance Kit included)
Karta s pamäťou flash s kapacitou 256 MB	57X9801	CS725de, CS720de, CS720dte, CS725dte, CS820dte, CS820dtfe, CS727de, CS728de, CS827de, CS421dn, CS521dn, CS622de, C2425dw, C2535dw, CS431dw, CS820de, MS321dn, B2338dw, MS421dn, MS421dw, B2442dw, MS521dn, MS621dn, B2650dn, MS622de, B2546dw, B2650dw, MS825dn, MS826de, MS725dvn, MS821n, MS821dn, MS822de, MS823n, MS823dn, B2865dw, MS331dn, CX725de, CX725dhe, CX725dthe, CX820dtfe, CX825dte, CX825dtfe, CX860dte, CX860dtfe, XC8155de, XC8155dte, XC8160de, CX727de, CX827de, CX421adn, CX522ade, CX622ade, CX625ade, CX625adhe, MC2425adw, MC2535adwe, MC2640adwe, CX522de, CX625de, CX622de, CX860de, CX825de, CX820de, MX321adn, MX321adw, MX421ade, MB2442adwe, MX521de, MX521ade, MX522adhe, MX622ade, MB2546adwe, MB2650adwe, MX822ade, MX822adxe, MX826ade, MX826adxe, MX722adhe, MX721ade, MX721adhe, MX722ade, MB2770adhwe, MX331adn, MX522dhe, MX622de, MX822de, MX722dhe, MX826de, MX722de
Karta so súpravou japonských znakov	57X9815	CS725de, CS720de, CS720dte, CS725dte, CS820dte, CS820dtfe, CS727de, CS728de, CS827de, CS421dn, CS521dn, CS622de, C2425dw, C2535dw, CS431dw, CS820de, MS321dn, B2338dw, MS421dn, MS421dw, B2442dw, MS521dn, MS621dn, B2650dn, MS622de, B2546dw, B2650dw, MS825dn, MS826de, MS725dvn, MS821n, MS821dn, MS822de, MS823n, MS823dn, B2865dw, MS331dn, CX725de, CX725dhe, CX725dthe, CX820dtfe, CX825dte, CX825dtfe, CX860dte, CX860dtfe, XC8155de, XC8155dte, XC8160de, CX727de, CX827de, CX421adn, CX522ade, CX622ade, CX625ade, CX625adhe, MC2425adw, MC2535adwe, MC2640adwe, CX522de, CX625de, CX622de, CX860de, CX825de, CX820de, MX321adn, MX321adw, MX421ade, MB2442adwe, MX521de, MX521ade, MX522adhe, MX622ade, MB2546adwe, MB2650adwe, MX822ade, MX822adxe, MX826ade, MX826adxe, MX722adhe, MX721ade, MX721adhe, MX722ade, MB2770adhwe, MX331adn, MX522dhe, MX622de, MX822de, MX722dhe, MX826de, MX722de

Popis	Číslo súčasti	Typ
		MB2338adw, MX421ade, MB2442adwe, MX521de, MX622ade, MX622adhe, MB2546adwe, MB2650adwe, MX822ade, MX822adxe, MX826ade, MX826adxe, MX722adhe, MX721ade, MX721adhe, MX722ade, MB2770adhwe, MX331adn, MX622de, MX822de, MX722dhe, MX826de, MX722de
Karta so súpravou kórejských znakov	57X9814	CS725de, CS720de, CS720dte, CS725dte, CS820dte, CS820dtfe, CS727de, CS728de, CS827de, CS421dn, CS521dn, CS622de, C2425dw, C2535dw, CS431dw, CS820de, MS321dn, B2338dw, MS421dn, MS421dw, B2442dw, MS521dn, MS621dn, B2650dn, MS622de, B2546dw, B2650dw, MS825dn, MS826de, MS725dvn, MS821n, MS821dn, MS822de, MS823n, MS823dn, B2865dw, MS331dn, CX725de, CX725dhe, CX725dthe, CX820dtfe, CX825dte, CX825dtfe, CX860dte, CX860dtfe, XC8155de, XC8155dte, XC8160de, CX727de, CX827de, CX421adn, CX522ade, CX622ade, CX625ade, CX625adhe, MC2425adw, MC2535adwe, MC2640adwe, CX522de, CX625de, CX622de, CX860de, CX825de, CX820de, MX321adn, MX321adw, MB2338adw, MX421ade, MB2442adwe, MX521de, MX622ade, MX622adhe, MB2546adwe, MB2650adwe, MX822ade, MX822adxe, MX826ade, MX826adxe, MX722adhe, MX721ade, MX721adhe, MX722ade, MB2770adhwe, MX331adn, MX622de, MX822de, MX722dhe, MX826de, MX722de
Karta so súpravou znakov tradičnej čínštiny	57X9810	CS725de, CS720de, CS720dte, CS725dte, CS820dte, CS820dtfe, CS727de, CS728de, CS827de, CS921de, CS923de, CS421dn, CS521dn, CS622de, C2425dw, C2535dw, CS431dw, CS820de, MS321dn, B2338dw, MS421dn, MS421dw, B2442dw, MS521dn, MS621dn, B2650dn, MS622de, B2546dw, B2650dw, MS825dn, MS826de, MS725dvn, MS821n, MS821dn, MS822de, MS823n, MS823dn, B2865dw, MS331dn, CX725de, CX725dhe, CX725dthe, CX820dtfe, CX825dte, CX825dtfe, CX860dte, CX860dtfe, XC8155de, XC8155dte, XC8160de, CX727de, CX827de, CX920de, CX921de, CX922de, CX923dte, CX923dxe, CX924dte, CX924dxe, CX421adn, CX522ade, CX622ade, CX625ade, CX625adhe, MC2425adw, MC2535adwe, MC2640adwe, CX522de, CX625de, CX622de, CX860de, CX825de, CX820de, MX321adn, MX321adw, MB2338adw, MX421ade, MB2442adwe, MX521de, MX622ade, MX622adhe, MB2546adwe, MB2650adwe, MX822ade, MX822adxe, MX826ade, MX826adxe, MX722adhe, MX721ade, MX721adhe, MX722ade, MB2770adhwe, MX331adn, MX622de, MX822de, MX722dhe, MX826de, MX722de
Karta so súpravou znakov zjednodušenej čínštiny	57X9812	CS725de, CS720de, CS720dte, CS725dte, CS820dte, CS820dtfe, CS727de, CS728de, CS827de, CS921de, CS923de, CS421dn, CS521dn, CS622de, C2425dw, C2535dw, CS431dw, CS820de, MS321dn, B2338dw, MS421dn, MS421dw, B2442dw, MS521dn, MS621dn, B2650dn, MS622de, B2546dw, B2650dw, MS825dn, MS826de, MS725dvn, MS821n, MS821dn, MS822de, MS823n, MS823dn, B2865dw, MS331dn, CX725de, CX725dhe, CX725dthe, CX820dtfe, CX825dte, CX825dtfe, CX860dte, CX860dtfe, XC8155de, XC8155dte, XC8160de, CX727de, CX827de, CX920de, CX921de, CX922de, CX923dte, CX923dxe, CX924dte, CX924dxe, CX421adn, CX522ade, CX622ade, CX625ade, CX625adhe, MC2425adw, MC2535adwe, MC2640adwe, CX522de, CX625de, CX622de, CX860de, CX825de, CX820de, MX321adn, MX321adw, MB2338adw, MX421ade, MB2442adwe, MX521de, MX622ade, MX622adhe, MB2546adwe, MB2650adwe, MX822ade, MX822adxe, MX826ade, MX826adxe, MX722adhe, MX721ade, MX721adhe, MX722ade, MB2770adhwe, MX331adn, MX622de, MX822de, MX722dhe, MX826de, MX722de
Pevný disk 320+ GB	27X0014	C925de, C792de, C792dte, C792e, C925dte, C950de, C748de, C746dn, C746dtn, C748dte, C746n, C748e, X746de
Pevný disk s kapacitou 500 GB	27X0200	CS517de, CS510de, CS510dte, C2132, MS817dn, MS818dn, MS812de, MS812dn, MS810de, MS811dn, MS810dn, MS812dtn, MS810n, MS811n, MS810dtn, MS811dtn, MS711dn, MS710dn, MS911de, MS812de with 2-Year Onsite Guarantee, M5155, M5163, M5170, MX717de, MX718de, MX711de, MX710de, XM5163, XM5170
Pevný disk s kapacitou 500 GB	27X0210	MS610de, MS610dte, M3150, M3150, MX517de, MX617de, MX611de, MX511de, MX510de, MX511dte, XM3150, XM1145, XM3150, XM3150 with 3-years Parts Only (Maintenance Kit included)
Pevný disk s kapacitou viac ako 500 GB	27X0400	CS725de, CS720de, CS720dte, CS725dte, CS820dte, CS820dtfe, CS727de, CS728de, CS827de, CS921de, CS923de, CS730de, CS735de, CS820de, CX725de, CX820dtfe, CX825dte, CX825dtfe, CX860dte, CX860dtfe, XC8155de, XC8155dte, XC8160de, CX727de, CX827de, CX920de, CX921de, CX922de, CX923dte, CX923dxe, CX924dte, CX924dxe, CX522ade, CX622ade, CX625ade, MC2535adwe, MC2640adwe, CX522de, CX625de, CX622de, CX735adse, CX730de,

Popis	Číslo súčasti	Typ
		CX833se, CX860de, CX825de, CX820de, MX622ade, MB2650adwe, MX722adhe, MX721ade, MX721adhe, MX722ade, MB2770adhwe, MX622de, MX722dhe, MX722de, MX532adwe, MX632adwe
Prídavný vyberateľný pevný disk	57X0070	CS730dn, CS735de, CS963e, C780n, C935dtn, C782n, C780dn, C782dn, C780dtn, C782dtn, C935dn, C935hdn, C935dtn, C734dn, C736dn, C736n, C736dtn, C734dtn, C734n, C734dw, C925de, C792de, C792dte, C792e, C792dhe, C925dte, C950de, C748de, C746dn, C746dtn, C748dte, C746n, C748e, MS817dn, MS818dn, W840, W840n, W840dn, T640, T640n, T642, T642n, T644, T644n, T642tn, T644tn, T640dtn, T642dtn, T644dtn, T640dn, T654dn, T652dn, T650dn, T654dtn, T654n, T652dtn, T652n, T650dtn, T650n, W850n, W850dn, T656dne, MS812de, MS812dn, MS810de, MS811dn, MS810dn, MS812dtn, MS810n, MS811n, MS810dtn, MS811dtn, MS711dn, MS710dn, MS911de, MS812de with 2-Year Onsite Guarantee, M5155, M5163, M5170, CX735adse, CX730de, CX961se, CX962se, CX963se, CX833se, CX950se, CX951se, X782e, X945e, X940e, X736de, X738de, X734de, X738dte, X792de, X792dte, X792dtfe, X792dtme, X792dtpe, X792dtse, X950de, X952de, X954de, X748de, X925de, X748dte, X746de, X950dhe, XS925de, XS950de, XS955de, MX717de, MX718de, MX953se, X646e MFP, X852e MFP, X646ef MFP, X651de, X652de, X654de, X656dte, X658dfe, X658dme, X658dtfe, X658dtme, X466de, X464de, X466dte, X466dwe, X463de, X864de 4, X862de 4, X860de 4, X860de 3, X862de 3, X864de 3, XS860de 4, XS862de 4, XS864de 4, MX812dfe, MX812dpe, MX812dxfe, MX812dxpe, MX812dme, MX812dxme, MX811dfe, MX811dpe, MX811dme, MX811dxfe, MX811dxpe, MX811dxme, MX810dfe, MX810dpe, MX810dme, MX810dxfe, MX810dxpe, MX810dxme, MX711de, MX710de, MX710dhe, MX711dhe, MX911de, MX910de, MX912de, MX910dxe, XM5163, XM5170, XM7155, XM7163, XM7170, XM7155x, XM7163x, XM7170x