

Lexmark Options Compatibility Table

Lexmark Authorized Service Technician will arrive at the customer location, generally the next business day, to install and prepare the printer for operation.

Description	Part #	Model
INSTALLATION SERVICE		
25xx Dot Matrix Install, De-Install Service	2349620	Forms Printer 2580, Forms Printer 2581, Forms Printer 2590, Forms Printer 2591, Forms Printer 2580n, Forms Printer 2581n, Forms Printer 2590n, Forms Printer 2591n
25xx+ Dot Matrix Install, De-Install Service	2354937	Forms Printer 2580n+, Forms Printer 2590n+, Forms Printer 2591+, Forms Printer 2580+, Forms Printer 2581+, Forms Printer 2590+, Forms Printer 2581n+, Forms Printer 2591n+
C540 Install, De-Install Service	2350431	C540n
C543 Install, De-Install Service	2350466	C543dn
C544 Install, De-Install Service	2350501	C544dn, C544dtn, C544dw
C546 Install, De-Install Service	2352725	C546dtn
C734 Install, De-Install Service	2350796	C734dn, C734dtn, C734dw
C736 Install, De-Install Service	2350814	C736dn, C736dtn
C746 Install, De-Install Service	2355003	C746dn
C748 Install, De-Install Service	2355031	C748de
C792 Install, De-Install Service	2353761	C792de, C792dte
C925 Install, De-Install Service	2353805	C925de
C935 Install, De-Install Service	2349467	C935dtn, C935dn, C935hdn
C950 Install, De-Install Service	2354214	C950de, C950dte
CS310 Install, De-Install Service	2356087	CS310dn, CS310n
CS410 Install, De-Install Service	2356133	CS410dn
CS510 Install, De-Install Service	2356179	CS510de
CX310 Install, De-Install Service	2356217	CX310dn
CX410 Install, De-Install Service	2356255	CX410de
CX510 Install, De-Install Service	2356293	CX510de, CX510dhe
E260 Install, De-Install Service	2350206	E260dn, E260d
E360 Install, De-Install Service	2350248	E360dn, E360d
E460 Install, De-Install Service	2350291	E460dn, E460dw, E462dtn
Lexmark Advanced Installation Service Group 1 Category A	2355260	CS410dn, CS310dn, CS310n, E360dn, E360d, E260dn, E260d, MS410dn, MS310dn, MS310d, MS312dn, MS415dn, CX410de, CX310dn, MX410de, MX310dn
MS310 Install, De-Install Service	2355655	MS310dn, MS310d, MS312dn
MS410 Install, De-Install Service	2355701	MS410dn, MS415dn
MS510 Install, De-Install Service	2355747	MS510dn
MS610 Install, De-Install Service	2355793	MS610de, MS610dn
MS810 Install, De-Install Service	2355839	MS810de, MS810dn, MS810n
MS811 Install, De-Install Service	2355885	MS811dn
MS812 Install, De-Install Service	2355931	MS812de, MS812dn
MS911 Install, De-Install Service	2357022	MS911de
MX310 Install, De-Install Service	2355495	MX310dn
MX410 Install, De-Install Service	2355533	MX410de
MX511 Install, De-Install Service	2355571	MX511de, MX511dhe
MX610, MX611 Install, De-Install Service	2355609	MX611de, MX611dhe
MX710 Install, De-Install Service	2355115	MX710de, MX710dhe
MX711 Install, De-Install Service	2355143	MX711de, MX711dhe
MX810 Install, De-Install Service	2355171	MX810dfe, MX810dme, MX810dxfe, MX810dxme
MX811 Install, De-Install Service	2355199	MX811dfe, MX811dme, MX811dxfe, MX811dxme
MX812 Install, De-Install Service	2355227	MX812dfe, MX812dxfe, MX812dme, MX812dxme
MX910 Install, De-Install Service	2357023	MX910de
MX911 Install, De-Install Service	2357024	MX911dte
MX912 Install, De-Install Service	2357025	MX912dxe
Standard Installation Service	2355247	MS610de, MS610dn, MS510dn, MS410dn, MS310dn, MS310d, MS312dn, MS415dn, CX522ade, MX421ade, MB3442i

Description	Part #	Model
Standard Installation Service	2355248	CS510de, CS410dn, CS310dn, CS310n, Forms Printer 2580n+, Forms Printer 2590n+, Forms Printer 2591+, Forms Printer 2580+, Forms Printer 2581+, Forms Printer 2590+, Forms Printer 2581n+, Forms Printer 2591n+, MS812de, MS812dn, MS810de, MS811dn, MS810dn, MS810n, MS711dn, MS710dn, MX511de, MX410de, MX511dhe, MX310dn
Standard Installation Service	2355251	C748de, C746dn, CX510de, CX410de, CX510dhe, CX310dn
T650 Install, De-Install Service	2350326	T650dn, T650dtn, T650n
T652 Install, De-Install Service	2350361	T652dn, T652dtn
T654 Install, De-Install Service	2350396	T654dn
T656 Install, De-Install Service	2352752	T656dne
W850 Install, De-Install Service	2351541	W850n, W850dn
X203 Install, De-Install Service	2351632	X203n
X204 Install, De-Install Service	2351633	X204n
X264 Install, De-Install Service	2350964	X264dn
X363 Install, De-Install Service	2351006	X363dn
X364 Install, De-Install Service	2351048	X364dn, X364dw
X463 Install, De-Install Service	2350886	X463de
X464 Install, De-Install Service	2350904	X464de
X466 Install, De-Install Service	2350922	X466de, X466dte, X466dwe
X543 Install, De-Install Service	2350519	X543dn
X544 Install, De-Install Service	2350537	X544dn, X544dtn, X544dw
X546 Install, De-Install Service	2352771	X546dtn
X548 Install, De-Install Service	2354326	X548dte, X548de
X651e, X652e Install, De-Install Service	2350555	X652de
X654e, X656e Install, De-Install Service	2350573	X654de, X656de, X656dte
X658e Install, De-Install Service	2350591	X658dfe, X658dme
X734 Install, De-Install Service	2350832	X734de
X736 Install, De-Install Service	2350850	X736de
X738 Install, De-Install Service	2350868	X738de, X738dte
X746 Install, De-Install Service	2355059	X746de
X748 Install, De-Install Service	2355087	X748de, X748dte
X792 Install, De-Install Service	2353783	X792de, X792dte
X925 Install, De-Install Service	2353827	X925de
X940e, X945e Install, De-Install Service	2349468	X945e, X940e
X950 Install, De-Install Service	2354242	X950de, X950dte
X954 Install, De-Install Service	2354298	X954de, X954dhe