Information Guide

Help menu

The Help menu consists of a series of Help pages that are stored in the printer as PDFs. They contain information about using the printer and performing printing tasks.

English, French, German, and Spanish translations are stored in the printer. Other translations are available at **http://support.lexmark.com**.

Use	To
Print All Guides	Print all the guides.
Print Quality	Print information about solving print quality issues.
Printing Guide	Print information about loading paper and other specialty media.
Media Guide	Print a list of the paper sizes supported in trays and feeders.
Print Defects Guide	Print information about resolving print defects.
Menu Map	Print a list of the printer control panel menus and settings.
Information Guide	Print a guide in locating additional information.
Connection Guide	Print information about connecting the printer locally (USB) or to a network.
Moving Guide	Print instructions for safely moving the printer.
Supplies Guide	Print part numbers for ordering supplies.

Setup sheet

The *Setup* sheet that comes with the printer provides information about setting up the printer.

Documentation CD

The *Documentation* CD that came with the printer includes a *User's Guide* and a *Quick Reference Guide*. The *User's Guide* provides information about loading paper, printing, ordering supplies, troubleshooting, clearing jams, maintaining the printer, customizing the home screen, and using solutions.

For updates, visit **http://support.lexmark.com**.

Home screen customization and using solutions

For information about customizing your home screen and using solutions, see the “Setting up and using the home screen applications” section in the *User's Guide*.

Additional language support

The *User's Guide* and the *Quick Reference Guide* are available in other languages on the *Documentation* CD. The *Networking Guide* is available in other languages on the *Software* CD.