

Furniture, Printer, Option, Scanner Compatibility

How to read this document	2
Supported maximum configurations for furniture stand 16C0369 and 16C0379	3
Supported maximum configurations for furniture stand 16C0389	4
Supported maximum printer configurations for base 22G0544	5
Supported maximum MFP configurations for the base 22G0544 with Scanner	6
Supported maximum configurations for base 22G0544 with scanner	7
Supported maximum configurations for printer stand 16N1708 with or without scanner shelf 10B1755	8
Supported maximum configurations for desktop use	9
Scanner shelf information	10
Envelope option	10
Legacy Furniture	11
Supported maximum configurations for base 10G0080	11
Supported maximum configurations for base 10G0080 with scanner	12
Click configuration of choice to see detail	

How to read this document

The following tables show the maximum possible configurations for the printer, MFP option, and furniture stand. See the following illustration on how to read the table.

This furniture stand supports these printers

Printers supported: T630, T630n, T632, T632n, T634, T634n

These scanner options are supported

Scanners supported: 3100, 3200, X4500

Types of options supported

Printer with:	MFP Option	Duplex	250-sheet drawers				500-sheet drawers				2000-sheet drawers
			1	2	3	4	1	2	3	4	1
	YES	YES	✓	✓	✓	✓					
	YES	YES	✓	✓	✓		✓				
	YES	YES	✓	✓			✓	✓			
	YES	YES	✓				✓	✓	✓		
	YES	NO					✓	✓		✓	
	YES	NO	✓				✓				✓
	YES	YES									✓

Each row represents a supported maximum configuration. An option removed from a particular row would still be an acceptable configuration.

For example, in the highlighted row, the supported configuration shows that:

- An MFP (scanner on top of a printer) with a duplexer, three 250-sheet drawers and one 500-sheet drawer is one of the maximum configurations possible on this particular furniture
- The configuration above is still acceptable with the removal of one or more of the options (scanner, duplexer, 250-sheet drawer or 500-sheet drawer)
- The configuration is not acceptable with any additional options listed in the chart

Supported maximum configurations for furniture stand 16C0369 and 16C0379



16C0369



16C0379

Printers supported: T630, T630n, T632, T632n, T634, T634n, T640, T640n, T642, T642n, T644, T644n

Scanners supported: 3100, 3200, X4500, 4600

MFPs supported: X630, X632, X632e, X632s, X634e, X646e, X644e, X642e

Printer with:	MFP Option	Duplex	250-sheet drawers				500-sheet drawers				2000-sheet drawers
			1	2	3	4	1	2	3	4	1
	YES	YES	✓	✓	✓	✓					
	YES	YES	✓	✓	✓		✓				
	YES	YES	✓	✓			✓	✓			
	YES	YES	✓				✓	✓	✓		
	YES	YES					✓	✓	✓	✓	
	YES	YES	✓	✓							✓
	YES	YES					✓				✓

Notes:

- The bottom of the printer should not reside more than 1.5 inches above the top surface of the printer furniture side shelves after installation.
- If a duplex option is installed:
 - The bottom of the duplex option should not reside more than 1.5 inches above the top surface of the printer furniture’s side shelves after installation.
 - The duplex unit must be directly under the printer for any of the listed configurations.
 - All paper handling options must be installed below the duplex unit.
- The 2000-sheet drawer option must be at the bottom of the stack of drawers.

Supported maximum configurations for furniture stand 16C0389



Printers supported: T630, T630n, T632, T632n, T634, T634n, T640, T640n, T642, T642n, T644, T644n

Scanners supported: 3100, 3200, X4500, 4600

MFPs supported: X630, X632, X632e, X632s, X634e, X644e, X646e, X642e

Printer with:	MFP Option	Duplex	250-sheet drawers				500-sheet drawers				2000-sheet drawers
			1	2	3	4	1	2	3	4	1
	YES	YES	✓	✓	✓	✓					
	YES	YES	✓	✓	✓		✓				
	YES	YES	✓	✓			✓	✓			
	YES	YES	✓				✓	✓	✓		
	YES	YES					✓	✓	✓	✓	
	YES	YES	✓	✓	✓						✓
	YES	YES	✓	✓			✓				✓
	YES	YES	✓				✓	✓			✓
	YES	YES					✓	✓	✓		✓

Notes:

- The bottom of the printer should not reside more than 1.5 inches above the top surface of the printer furniture side shelves after installation.
- If a duplex option is installed:
 - The bottom of the duplex option should not reside more than 1.5 inches above the top surface of the printer furniture’s side shelves after installation.
 - The duplex unit must be directly under the printer for any of the listed configurations.
 - All paper handling options must be installed below the duplex unit.
- The 2000-sheet drawer option must be at the bottom of the stack of drawers.
- Stability requirement—Stability tabs included with the furniture must be installed to meet safety requirements.

Supported maximum printer configurations for base 22G0544



Printers supported: T630, T630n, T632, T632n, T634, T634n, T640, T640n, T642, T642n, T644, T644n,

MFPs supported: [See the next page](#)

Printer with:	MFP Option	Duplex	250-sheet drawers				500-sheet drawers				2000-sheet drawers
			1	2	3	4	1	2	3	4	1
	NO	YES	✓	✓	✓	✓					
	NO	YES	✓	✓	✓		✓				
	NO	YES	✓	✓			✓	✓			
	NO	YES	✓				✓	✓	✓		
	NO	YES					✓	✓	✓	✓	
	NO	YES	✓	✓	✓						✓
	NO	YES	✓				✓				✓
	NO	YES					✓	✓			✓

Notes:

- If a duplex option is installed:
 - The duplex unit must be directly under the printer for any of the listed configurations.
 - All paper handling options must be installed below the duplex unit.
- The 2000-sheet drawer option must be at the bottom of the stack of drawers.
- At least one input drawer option is required with this base.

Supported maximum MFP configurations for the base 22G0544 with Scanner



MFPs supported: X646e, X644e, X642e

Printer with:	Duplex	250-sheet drawers				500-sheet drawers				10-Inch Cabinet Option	2000-sheet drawers
		1	2	3	4	1	2	3	4		
	YES	✓	✓	✓	✓						
	YES	✓	✓	✓		✓					
	YES	✓	✓			✓	✓				
	YES	✓				✓	✓	✓			
	YES					✓	✓	✓	✓		
	YES	✓	✓							✓	
	YES					✓	✓			✓	
	YES	✓				✓				✓	
	YES	✓									✓
	YES					✓					✓

Notes:

- If a duplex option is installed:
 - The duplex unit must be directly under the printer for any of the listed configurations.
 - All paper handling options must be installed below the duplex unit.
- The 2000-sheet drawer option must be at the bottom of the stack of drawers.
- The 10-inch cabinet option must be at the bottom of the stack of drawers.
- At least one input drawer or 10-inch cabinet option is required with this base.

Supported maximum configurations for base 22G0544 with scanner



Printers supported: T630, T630n, T632, T632n, T634, T634n, T642, T642n, T644, T644n

Scanners supported: 3100, 3200, X4500, 4600

MFPs supported: X630, X632, X632e, X632s, X634e

Printer with:	MFP Option	Duplex	250-sheet drawers				500-sheet drawers				10-inch cabinet option	2000-sheet drawers
			1	2	3	4	1	2	3	4		
	YES	YES	✓	✓	✓	✓						
	YES	YES	✓	✓	✓		✓					
	YES	YES	✓				✓	✓				
	YES	YES	✓	✓			✓	✓				
	YES	YES					✓	✓	✓			
	YES	YES										✓
	YES	YES					✓				✓*	

Notes:

- If a duplex option is installed:
 - The duplex unit must be directly under the printer for any of the listed configurations.
 - All paper handling options must be installed below the duplex unit.
- The 2000-sheet drawer option must be at the bottom of the stack of drawers.
- At least one input drawer option is required with this base.
- * only for use in combination with the 4600 scanner option.
- The 10-inch cabinet option must be at the bottom of the stack of drawers.
- At least one input drawer or 10-inch cabinet option is required with this base.

Supported maximum configurations for printer stand 16N1708 with or without scanner shelf 10B1755



Printers supported: C760, C762

Scanners supported: X4500

MFPs supported: X762e

Printer with:	MFP Option	Duplex	500-sheet drawers		
			1	2	3
	YES	YES	✓		
	YES	NO	✓	✓	
	NO	YES	✓	✓	✓

Notes:

- If a duplex option is installed:
 - The duplex unit must be directly under the printer for any of the listed configurations.
 - All paper handling options must be installed below the duplex unit.
- Printer (without MFP) can also support a maximum combination of one optional 2000-sheet drawer plus one optional 500-sheet drawer (with or without duplex). The printer stand 16N1708 is not used with the 2000-sheet drawer. An optional 500-sheet drawer is required when utilizing a 2000-sheet drawer and duplex unit. (The first option under a duplex unit must be a 500-sheet drawer.)

Supported maximum configurations for desktop use



Printers supported: T630, T630n, T632, T632n, T634, T634n, T640, T640n, T642, T642n, T644, T644n

Scanners supported: 3100, 3200, X4500

MFPs supported: X630, X632, X632e, X632s, X634e, X644e, X646e, X642e

MFP or MFP Option configured with:	MFP Option	Duplex	250-sheet drawers				500-sheet drawers				2000-sheet drawers
			1	2	3	4	1	2	3	4	1
	YES	YES	✓								
	YES	NO	✓	✓							
	YES	YES					✓				
	YES	NO	✓				✓				
	NO	YES	✓	✓	✓						
	NO	NO	✓	✓	✓	✓					
	NO	YES	✓	✓			✓				
	NO	NO	✓	✓	✓		✓				
	NO	YES					✓	✓			
	NO	NO	✓				✓	✓			
	NO	NO					✓	✓	✓		
	NO	YES									✓

Notes:

- Be sure the total height of the selected configuration is appropriate for your office environment.
- If a duplex option is installed:
 - The duplex unit must be directly under the printer for any of the listed configurations.
 - All paper handling options must be installed below the duplex unit.

Scanner shelf information

In order to place an MFP option on top of a monochrome printer, you must use one of the following shelves:

- Part number **16A0503**, which supports the following configurations:
 - MFP option X242 and X443 for T5XX, T61X, T62X printers.
 - MFP option 3100 and 3200 for T63X printers.
 - MFP X630, X632, X632s
- Part number **10G1000**, which supports the following configurations:
 - MFP option X4500 for T632 and T634 printers.
 - MFP X632e, X634e (shelf included)
- Part number **21J0050**, which supports the following configurations:
 - MFP option 4600 for T642(n) and T644(n) printers.

Notes:

- If an MFP option and scanner shelf are installed, no output options are allowed in the configuration.
- If an MFP option and scanner shelf are *not* installed, all output options are supported.
- Scanner shelves must be attached directly to the printer.

Envelope option

The envelope option can be added to any configuration. See the printer documentation for more information on installing the envelope option.

Legacy Furniture

Supported maximum configurations for base 10G0080



Printers supported: T630, T630n, T632, T632n, T634, T634n, T640, T640n, T642, T642n, T644, T644n

MFPs supported: [See the next page](#)

Printer with:	MFP Option	Duplex	250-sheet drawers				500-sheet drawers				2000-sheet drawers
			1	2	3	4	1	2	3	4	1
	NO	YES	✓	✓	✓	✓					
	NO	YES	✓	✓	✓		✓				
	NO	YES	✓	✓			✓	✓			
	NO	YES	✓				✓	✓	✓		
	NO	YES					✓	✓	✓	✓	
	NO	YES	✓	✓	✓						✓
	NO	YES	✓				✓				✓
	NO	YES					✓	✓			✓

Notes:

- If a duplex option is installed:
 - The duplex unit must be directly under the printer for any of the listed configurations.
 - All paper handling options must be installed below the duplex unit.
- The 2000-sheet drawer option must be at the bottom of the stack of drawers.
- At least one input drawer option is required with this base.

Supported maximum configurations for base 10G0080 with scanner



Printers supported: T630, T630n, T632, T632n, T634, T634n

Scanners supported: 3100, 3200, X4500

MFPs supported: X630, X632, X632e, X632s, X634e

Printer with:	MFP Option	Duplex	250-sheet drawers				500-sheet drawers				2000-sheet drawers
			1	2	3	4	1	2	3	4	1
	YES	YES	✓	✓	✓	✓					
	YES	YES	✓	✓	✓		✓				
	YES	YES	✓				✓	✓			
	YES	NO	✓	✓			✓	✓			
	YES	YES					✓	✓	✓		
	YES	YES									✓

Notes:

- If a duplex option is installed:
 - The duplex unit must be directly under the printer for any of the listed configurations.
 - All paper handling options must be installed below the duplex unit.
- The 2000-sheet drawer option must be at the bottom of the stack of drawers.

At least one input drawer option is required with this base.