



ISO/IEC 19798 Yield Test Report

CX622/CX625 Toner Cartridge

Printer: CX622ade/CX625ade/CX625adhe

Part Numbers of Cartridges:

Cyan (C) 78C00CG, 78Cx0C0, 78Cx0CE,
42CCL01C, 42CCG01C

Yellow (Y) 78C00YG, 78Cx0Y0, 78Cx0YE,
42CCL01Y, 42CCG01Y

Magenta (M) 78C00MG, 78Cx0M0, 78Cx0ME,
42CCL01M, 42CCG01M

Black (K) 78Cx0K0, 78Cx0KE, 78C00KG,
42CCL02K, 42CCG02K

Lexmark Toner Cartridge Yield Claim:

Average Continuous Composite Color (CMY) Cartridge Yield	1,400	standard pages
Average Continuous Black (K) Cartridge Yield	2,000	standard pages
Declared yield in accordance with ISO/IEC 19798		

Tested Cartridge Summary:

90% Lower Confidence
 Composite Color (CMY) = **1,811** pages
 Black = **2,359** pages

For questions concerning testing contact:

Lexmark International Inc.
 740 West New Circle Rd.
 Lexington, Ky. 40550 USA
 Attn: Laser Supplies Product Manager

Date Tested

	19-Dec-2017	20-Dec-2017			
Number of cartridges in testing		C= 9	M= 9	Y= 9	K= 9
Qty. of cartridges used in calculation		C= 9	M= 9	Y= 9	K= 9
Type of cartridge		Replenishment			
Shake Procedure		No Shake			
1st shake		No Shake			
2nd shake		Continuous			
Print mode		4			
Number of printers tested		Hammermill Tidal MP - 20 lbs. - Letter			
Media used		Short Edge Feed (SEF)			
Paper feed orientation		B2			
Driver version		Windows 7 Professional			
Operating system		Adobe Reader 9.4			
Application software		ISO-IEC_24712_2007.pdf			
Test page version		ON			
Power (off/on) everyday		Y			
Pre-generated file used		Y			
Header / Footer used		Intel(R) Core™ i7-4770 CPU @ 3.40 GHz			
Computer Model		16.0 GB			
Computer RAM and CPU type		Network			
PC / Printer connection					

Comments :

The print file was generated with number of copies set equal to 2.



ISO/IEC 19798 Yield Test Report

Printer	Color	Cartridge SN	Temperature C / F			Humidity			Cartridge Yield	Cartridge used in Calculation
			Avg	Max	Min	Avg	Max	Min		
7529PTBJUP130	C	CAH173390061	23 / 73	24 / 75	22 / 72	51	53	49	1905	Y
7529PTBJUP130	C	CAH173390053	23 / 73	24 / 75	22 / 72	51	53	49	1955	Y
7529PTBJUP130	C	CAH173390065	23 / 73	24 / 75	22 / 72	51	53	49	1920	Y
5029PTBZEU250	C	CAH173390056	23 / 73	24 / 75	22 / 72	51	53	49	2220	Y
5029PTBZEU250	C	CAH173390058	23 / 73	24 / 75	22 / 72	51	53	49	1955	Y
5029PTBZEU250	C	CAH173390051	23 / 73	24 / 75	22 / 72	51	53	49	1795	Y
5029PTBZEU251	C	CAH173390055	23 / 73	24 / 75	22 / 72	51	53	49	1940	Y
5029PTBZEU251	C	CAH173390054	23 / 73	24 / 75	22 / 72	51	53	49	1925	Y
5029PTBZEU251	C	CAH173390062	23 / 73	24 / 75	22 / 72	51	53	49	1845	Y
7529PTBJUP130	K	CAH173390214	23 / 73	24 / 75	22 / 72	51	53	49	2480	Y
7529PTBJUP130	K	CAH173390232	23 / 73	24 / 75	22 / 72	51	53	49	2650	Y
5029PTBZEU250	K	CAH17339020F	23 / 73	24 / 75	22 / 72	51	53	49	2265	Y
5029PTBZEU250	K	CAH173390222	23 / 73	24 / 75	22 / 72	51	53	49	2895	Y
5029PTBZEU250	K	CAH173390226	23 / 73	24 / 75	22 / 72	51	53	49	2095	Y
5029PTBZEU251	K	CAH17339020E	23 / 73	24 / 75	22 / 72	51	53	49	2740	Y
5029PTBZEU251	K	CAH17339021F	23 / 73	24 / 75	22 / 72	51	53	49	2500	Y
7529PTBJUP130	K	CAH173390221	23 / 73	24 / 75	22 / 72	51	53	49	2590	Y
5029PTBZEU251	K	CAH173390220	23 / 73	24 / 75	22 / 72	51	53	49	2380	Y
7529PTBJUP130	M	CAH1733900EF	23 / 73	24 / 75	22 / 72	51	53	49	2015	Y
7529PTBJUP130	M	CAH17339010A	23 / 73	24 / 75	22 / 72	51	53	49	1710	Y
5029PTBZEU250	M	CAH1733900EE	23 / 73	24 / 75	22 / 72	51	53	49	2150	Y
5029PTBZEU250	M	CAH1733900FC	23 / 73	24 / 75	22 / 72	51	53	49	1995	Y
5029PTBZEU250	M	CAH173390102	23 / 73	24 / 75	22 / 72	51	53	49	2055	Y
5029PTBZEU251	M	CAH1733900F1	23 / 73	24 / 75	22 / 72	51	53	49	1645	Y
5029PTBZEU251	M	CAH173390103	23 / 73	24 / 75	22 / 72	51	53	49	1835	Y
5029PTBZEU251	M	CAH173390108	23 / 73	24 / 75	22 / 72	51	53	49	1715	Y
7529PTBJUP130	M	CAH1733900F7	23 / 73	24 / 75	22 / 72	51	53	49	1760	Y
7529PTBJUP130	Y	CAH173390183	23 / 73	24 / 75	22 / 72	51	53	49	1950	Y
7529PTBJUP130	Y	CAH17339017E	23 / 73	24 / 75	22 / 72	51	53	49	1990	Y
5029PTBZEU250	Y	CAH173390172	23 / 73	24 / 75	22 / 72	51	53	49	2200	Y
5029PTBZEU250	Y	CAH173390182	23 / 73	24 / 75	22 / 72	51	53	49	2140	Y
5029PTBZEU250	Y	CAH173390184	23 / 73	24 / 75	22 / 72	51	53	49	1750	Y
5029PTBZEU251	Y	CAH173390171	23 / 73	24 / 75	22 / 72	51	53	49	1620	Y
5029PTBZEU251	Y	CAH173390185	23 / 73	24 / 75	22 / 72	51	53	49	1945	Y
5029PTBZEU251	Y	CAH17339017C	23 / 73	24 / 75	22 / 72	51	53	49	1740	Y
7529PTBJUP130	Y	CAH173390175	23 / 73	24 / 75	22 / 72	51	53	49	1960	Y

	Average	Std Dev. Of Sample	90% Lower Confidence
Cyan Cartridge	1940	118	1867
Magenta Cartridge	1876	181	1763
Yellow Cartridge	1922	189	1804
CMY Composite			1811
Black Cartridge	2511	244	2359