

ISO/IEC 19798 Yield Test Report

MC2640 Toner Cartridge

Printer: MC2640adwe

Part Numbers of Cartridges:

Cyan (C) 42CCL14C, 42C8499
Magenta (M) 42CCL14M, 42C8500

Yellow (Y) 42CCL14Y, 42C8501
Black (K) 42CBL03K, 42C8502

Lexmark Toner Cartridge Yield Claim:

Average Continuous Composite Color (CMY) Cartridge Yield	1,400	standard pages
Average Continuous Black (K) Cartridge Yield	3,000	standard pages
Declared yield in accordance with ISO/IEC 19798		

Tested Cartridge Summary:

90% Lower Confidence
 Composite Color (CMY) = **1,811** pages
 Black = **3,312** pages

For questions concerning testing contact:

Lexmark International Inc.
 740 West New Circle Rd.
 Lexington, Ky. 40550 USA
 Attn: Laser Supplies Product Manager

Date Tested

	19-Dec-2017	21-Dec-2017			
Number of cartridges in testing		C= 9	M= 9	Y= 9	K= 9
Qty. of cartridges used in calculation		C= 9	M= 9	Y= 9	K= 9
Type of cartridge		Replenishment			
Shake Procedure		No Shake			
1st shake		No Shake			
2nd shake		Continuous			
Print mode		3			
Number of printers tested		Hammermill Tidal MP - 20 lbs. - Letter			
Media used		Short Edge Feed (SEF)			
Paper feed orientation		B2			
Driver version		Windows 7 Professional			
Operating system		Adobe Reader 9.4			
Application software		ISO-IEC_24712_2007.pdf			
Test page version		ON			
Power (off/on) everyday		Y			
Pre-generated file used		Y			
Header / Footer used		Intel(R) Core™ i5-2520M CPU @ 2.50 GHz			
Computer Model		4.0 GB			
Computer RAM and CPU type		Network			
PC / Printer connection					

Comments and or exceptions:

*The print file was generated with number of copies set equal to 2.

ISO/IEC 19798 Yield Test Report

Printer	Color	Cartridge SN	Temperature C / F			Humidity			Cartridge Yield	Cartridge used in Calculation
			Avg	Max	Min	Avg	Max	Min		
7529PTBJUP130	C	CAH173390061	23 / 73	24 / 75	22 / 72	51	53	48	1905	Y
7529PTBJUP130	C	CAH173390053	23 / 73	24 / 75	22 / 72	51	53	48	1955	Y
7529PTBJUP130	C	CAH173390065	23 / 73	24 / 75	22 / 72	51	53	48	1920	Y
5029PTBZEU250	C	CAH173390056	23 / 73	24 / 75	22 / 72	51	53	48	2220	Y
5029PTBZEU250	C	CAH173390058	23 / 73	24 / 75	22 / 72	51	53	48	1955	Y
5029PTBZEU250	C	CAH173390051	23 / 73	24 / 75	22 / 72	51	53	48	1795	Y
5029PTBZEU251	C	CAH173390055	23 / 73	24 / 75	22 / 72	51	53	48	1940	Y
5029PTBZEU251	C	CAH173390054	23 / 73	24 / 75	22 / 72	51	53	48	1925	Y
5029PTBZEU251	C	CAH173390062	23 / 73	24 / 75	22 / 72	51	53	48	1845	Y
7529PTBJUP130	K	CAH173392631	23 / 73	24 / 75	22 / 72	51	53	48	3505	Y
7529PTBJUP130	K	CAH17339264D	23 / 73	24 / 75	22 / 72	51	53	48	3730	Y
5029PTBZEU250	K	CAH173392630	23 / 73	24 / 75	22 / 72	51	53	48	3680	Y
5029PTBZEU250	K	CAH17339264E	23 / 73	24 / 75	22 / 72	51	53	48	2835	Y
5029PTBZEU250	K	CAH17339263F	23 / 73	24 / 75	22 / 72	51	53	48	3340	Y
5029PTBZEU251	K	CAH17339264A	23 / 73	24 / 75	22 / 72	51	53	48	4015	Y
5029PTBZEU251	K	CAH173392634	23 / 73	24 / 75	22 / 72	51	53	48	3445	Y
7529PTBJUP130	K	CAH173392633	23 / 73	24 / 75	22 / 72	51	53	48	3395	Y
5029PTBZEU251	K	CAH173392632	23 / 73	24 / 75	22 / 72	51	53	48	3710	Y
7529PTBJUP130	M	CAH1733900EF	23 / 73	24 / 75	22 / 72	51	53	48	2015	Y
7529PTBJUP130	M	CAH17339010A	23 / 73	24 / 75	22 / 72	51	53	48	1710	Y
5029PTBZEU250	M	CAH1733900EE	23 / 73	24 / 75	22 / 72	51	53	48	2150	Y
5029PTBZEU250	M	CAH1733900FC	23 / 73	24 / 75	22 / 72	51	53	48	1995	Y
5029PTBZEU250	M	CAH173390102	23 / 73	24 / 75	22 / 72	51	53	48	2055	Y
5029PTBZEU251	M	CAH1733900F1	23 / 73	24 / 75	22 / 72	51	53	48	1645	Y
5029PTBZEU251	M	CAH173390103	23 / 73	24 / 75	22 / 72	51	53	48	1835	Y
5029PTBZEU251	M	CAH173390108	23 / 73	24 / 75	22 / 72	51	53	48	1715	Y
7529PTBJUP130	M	CAH1733900F7	23 / 73	24 / 75	22 / 72	51	53	48	1760	Y
7529PTBJUP130	Y	CAH173390183	23 / 73	24 / 75	22 / 72	51	53	48	1950	Y
7529PTBJUP130	Y	CAH17339017E	23 / 73	24 / 75	22 / 72	51	53	48	1990	Y
5029PTBZEU250	Y	CAH173390172	23 / 73	24 / 75	22 / 72	51	53	48	2200	Y
5029PTBZEU250	Y	CAH173390182	23 / 73	24 / 75	22 / 72	51	53	48	2140	Y
5029PTBZEU250	Y	CAH173390184	23 / 73	24 / 75	22 / 72	51	53	48	1750	Y
5029PTBZEU251	Y	CAH173390171	23 / 73	24 / 75	22 / 72	51	53	48	1620	Y
5029PTBZEU251	Y	CAH173390185	23 / 73	24 / 75	22 / 72	51	53	48	1945	Y
5029PTBZEU251	Y	CAH17339017C	23 / 73	24 / 75	22 / 72	51	53	48	1740	Y
7529PTBJUP130	Y	CAH173390175	23 / 73	24 / 75	22 / 72	51	53	48	1960	Y

	Average	Std Dev. Of Sample	90% Lower Confidence
Cyan Cartridge	1940	118	1867
Magenta Cartridge	1876	181	1763
Yellow Cartridge	1922	189	1804
CMY Composite			1811
Black Cartridge	3517	331	3312